



FITTING INSTRUCTIONS FOR


# Rear Door Drop Down Table

SKU

**KS0481**

COMPATIBILITY

**Mitsubishi Pajero Gen 3 (NM-NP)**



## Included contents

QTY	COMPONENT	QTY	COMPONENT
1	Rear Door Table	2	Plastic Cord Button
2	Mounting Brackets (LHS/RHS)	2	Paracord 670mm
2	M8 Nyloc Nut	8	Self Tapping Screw
2	M8 x 16 Button Head Socket Screw	10	M5 x 15 x 1.2 DIN Flat Washer
2	M8 x 17 x 1.2 Washer	2	M5 Nyloc Nut
2	M5 x 16 Button Head Socket Screw		



**Time**



30 minutes / Half a beer

For further information contact KAON on **07 3180 1470** or [info@kaon.com.au](mailto:info@kaon.com.au)

# Let's get to work.

## Bracket Installation

1. Position the RHS bracket on the rear door, as pictured. Allow a 30mm gap to the trim line above, and 25mm to the trim edge on the right. Mark the position with a pencil.
2. Use a 3mm bit to drill a pilot hole. Using one of the supplied self tapping screws, secure the top in place.
3. Position the LHS bracket on the rear door, as pictured. Allow 30mm above, and ensure it is positioned 1088mm across from the RHS bracket, from outer to outer. Mark the position with a pencil before drilling a pilot hole.
4. Secure the top in place with a self tapping screw.
5. Ensure both brackets are square before marking the placement of the remaining 3 holes on each with a pencil.
6. Drill the remaining holes of the bracket and insert the self tapping screws in place.
7. Whatever you do, **DO NOT OVERTIGHTEN** the screws.





## Table Installation

8. Attach the table to the LHS bracket using the M8 button head screw and M8 round washer and tighten with the M8 nyloc nut. Ensure the table sits on the outside of the bracket and the washer is between the table and the bracket.
9. Repeat the process for the RHS table bracket.

**If you are also installing the Kitchenette Clip-In Sink Extension:** Sandwich the supplied tab bracket between the washer and table on the RHS. Position the tab bracket so the holes line up and the tab bracket hangs over the right-hand side of the table, as pictured.

10. Tighten the bolts so that there is some resistance, whilst still letting the table open and close easily.
11. To attach the support line, weave the supplied paracord through the holes of the bracket to the table as shown and tie in place. Repeat on other side.
12. To install the button, align the button in the hole on the outer surface of the table and affix using the M5 x 16 dome head bolt and nyloc nut.
13. Last up, gently close the door to ensure it clears any drawer systems or accessories you have fitted.
14. That's it, you're finished!
15. If you're installing a Kitchenette Clip-In Sink Extension or a Clip-In Chopping Board, refer to the instructions provided with them.





## **Local Knowledge & Assistance**

We know half the fun of building your dream 4x4 is getting your hands dirty. But we also know that sometimes, things don't go to plan. If in the pursuit to build the ultimate setup you find yourself off-track, we're here to help you get unstuck.

**For further information call 07 3180 1470 or email [info@kaon.com.au](mailto:info@kaon.com.au)**

Disclaimer: The products sold by KAON should not be modified, and are for use only on the vehicles specifically stated. KAON will not be liable for any damages arising out of the use or misuse of its products. It is the customers responsibility to ensure the products are safely and properly used and installed. KAON consistently seeks to improve its products and reserves the right to make changes to any product.