



FITTING INSTRUCTIONS FOR


Rear Door Drop Down Table

SKU

KS0481

COMPATIBILITY

Mitsubishi Pajero Gen 3 (NM-NP)



Included contents

QTY	COMPONENT	QTY	COMPONENT
1	Rear Door Table	2	Plastic Cord Button
2	Mounting Brackets (LHS/RHS)	2	Lengths of Paracord
2	M8 Nyloc Nut	8	Self Tapping Screw
2	M8 x 16 Button Head Socket Screw	8	M5 x 15 x 1.2 DIN Flat Washer
2	M8 x 17 x 1.2 Washer	2	M5 Nyloc Nut



Time

30 minutes / Half a beer

For further information contact KAON on **07 3180 1470** or info@kaon.com.au

Let's get to work.

Bracket Installation

1. Position the RHS bracket on the rear door, as pictured. Allow a 30mm gap to the trim line above, and 25mm to the trim edge on the right. Mark the position with a pencil.
2. Use a 3mm bit to drill a pilot hole. Using one of the supplied self tapping screws, secure the top in place.
3. Position the LHS bracket on the rear door, as pictured. Allow 30mm above, and ensure it is positioned 1088mm across from the RHS bracket, from outer to outer. Mark the position with a pencil before drilling a pilot hole.
4. Secure the top in place with a self tapping screw.
5. Ensure both brackets are square before marking the placement of the remaining 3 holes on each with a pencil.
6. Drill the remaining holes of the bracket and insert the self tapping screws in place.
7. Whatever you do, **DO NOT OVERTIGHTEN** the screws.





Table Installation

1. First up, remove the plastic protective layer to reveal your shiny new rear door table.
2. Attach the table using the M8 button head screws, washers and nyloc nuts. Ensure the table sits on the outside of the bracket and the washer is between the table and the bracket.
3. Repeat on the other side.
4. To attach the support line, weave the supplied paracord through the holes of the bracket to the table as shown and tie in place. Repeat on other side.
5. To install the button, align the button in the hole on the outer surface of the table and affix using the M5 x 16 dome head bolt and nyloc nut.
6. Last up, gently close the door to ensure it clears any drawer systems or accessories you have fitted.
7. That's it, you're finished!



Bolt Torque

DIAMETER (mm)	5mm	6mm	8mm	10mm	12mm
NEWTON-METRES (Nm)	5 Nm	9 Nm	22 Nm	44 Nm	77 Nm



Local Knowledge & Assistance

We know half the fun of building your dream 4x4 is getting your hands dirty. But we also know that sometimes, things don't go to plan. If in the pursuit to build the ultimate setup you find yourself off-track, we're here to help you get unstuck.

For further information call 07 3180 1470 or email info@kaon.com.au

Disclaimer: The products sold by KAON should not be modified, and are for use only on the vehicles specifically stated. KAON will not be liable for any damages arising out of the use or misuse of its products. It is the customers responsibility to ensure the products are safely and properly used and installed. KAON consistently seeks to improve its products and reserves the right to make changes to any product.