



FITTING INSTRUCTIONS FOR


# Out-Back Gas Bottle Mount

SKU

**KS0403**

COMPATIBILITY

**Out-Back Spare Tyre Mount**



## Included contents

QTY	COMPONENT
1	Out-Back Gas Bottle Mount
2	Foot Clamp
2	M10 Knob
4	M8 x 24 x 2.0 DIN Flat Washer
2	M8 x 20 Hex Bolt
2	M8 Nyloc Nut

## Also required

QTY	COMPONENT
1	Out-Back Spare Tyre Mount & Strap



**Time**

5 minutes / A sip of beer!

For further information contact KAON on **07 3180 1470** or [info@kaon.com.au](mailto:info@kaon.com.au)

<b>Bolt Torque</b>					
<b>DIAMETER (mm)</b>	5mm	6mm	8mm	10mm	12mm
<b>NEWTON-METRES (Nm)</b>	5 Nm	9 Nm	22 Nm	44 Nm	77 Nm

# Let's get to work.

## Installation

**PLEASE NOTE:** Before installing the gas bottle mount it is strongly advised that you check the laws, rules and regulations for the transportation of gas bottles in your area.

1. First up is to attach the Gas Bottle Mount to the Spare Tyre Mount. We recommend sitting the mounts up against the tyre to work out what positioning will work best for your setup, ensuring that your rear door or rear bar swingaway are able to open unaffected.
2. Secure the Gas Bottle Mount to the Spare Tyre Mount using the M8 bolts, nuts and washers.
3. Position the Spare Tyre Mount on the tyre, and secure with the provided ratchet strap. We advise ensuring that the hooks are facing outwards with the ratchet at the top of the tyre.
4. Place the Foot Clamps through the gaps in the gas bottle rim as shown.
5. Thread the M10 knobs into the Foot Clamps and tighten until secure.
6. Carefully double check clearance between the product and vehicle by gently opening the rear door until it's fully open. **Failure to do this may result in damage to the product and/or vehicle.**
7. That's it, you're ready to hit the road and cook up a storm! The M10 knobs should be secure in most driving conditions, but If you prefer a little added security, we've also provided two additional sets of slots for a cam lock style strap.





## **Local Knowledge & Assistance**

We know half the fun of building your dream 4x4 is getting your hands dirty. But we also know that sometimes, things don't go to plan. If in the pursuit to build the ultimate setup you find yourself off-track, we're here to help you get unstuck.

**For further information call 07 3180 1470 or email [info@kaon.com.au](mailto:info@kaon.com.au)**

Disclaimer: The products sold by KAON should not be modified, and are for use only on the vehicles specifically stated. KAON will not be liable for any damages arising out of the use or misuse of its products. It is the customers responsibility to ensure the products are safely and properly used and installed. KAON consistently seeks to improve its products and reserves the right to make changes to any product.