



FITTING INSTRUCTIONS FOR


Rear Cargo Crates

SKU


KS0876/ 877

COMPATIBILITY

Ineos Grenadier Wagon Models



KS0876 (LHS)



KS0877 (RHS)

KS0876 Included contents

QTY	COMPONENT
1	Cargo Crate (LHS)
7	Self Tapping Screw
7	M5 x 16 x 1.0 DIN Washer



Time

30 minutes / Half a beer

KS0877 Included contents

QTY	COMPONENT
1	Cargo Crate (RHS)
1	Cargo Crate Brace
10	Self Tapping Screw
10	M5 x 16 x 1.0 DIN Washer
2	M6 x 12 Button Head Socket Screw
2	M6 Flanged Nut

For further information contact KAON on **07 3180 1470** or info@kaon.com.au



G8.8 Bolt Torque (Non-Lubricated)

DIAMETER (mm)	5mm	6mm	8mm	10mm	12mm
NEWTON-METRES (Nm)	6 Nm	10 Nm	15 Nm	22 Nm	35 Nm

Let's get to work.



Left Cargo Crate Installation (KS0876)

1. Mock-up the position of the cargo crate in the left hand side of the car's rear boot space. Ensure that the crate is seated correctly and follows the curvature of the trim.
2. With the crate's position confirmed, mark the position of each bolt hole.
3. Remove the crate from the car, and using a 3mm drill bit, drill a hole in each marked point.
4. Place the crate back into position, and use Self Tapping Screws and M5 Washers to loosely secure each mounting point.
5. Tighten each screw until secure. Ensure that you don't over-tighten, as this can strip the hole.
6. That's it – you're done!
If you're installing a cargo crate on the right hand side of the vehicle, you can continue on with the installation for that now.



Right Cargo Crate Installation (KS0877)

7. Secure the Brace to the Cargo Crate, using the provided M6 hardware. The brace can be secured to the positions circled in red, as pictured. If you have something specific you wish to store, it's best to account for its size now. If you are unsure, we recommend the central mounting position to maximise support for the crate.
8. Mock-up the position of the cargo crate in the right hand side of the car's rear boot space. Ensure that the crate is seated correctly and follows the curvature of the trim.
9. With the crate's position confirmed and a small amount of pressure applied to it, mark the position of each bolt hole.
10. Remove the crate from the car, and using a 3mm drill bit, drill a hole in each marked point.
11. Place the crate back into position, and use Self Tapping Screws and M5 Washers to loosely secure each mounting point.
12. Apply pressure to the crate and tighten each screw until secure. Ensure that you don't over-tighten, as this can strip the hole.
13. That's it – you're done!
Now you can use your additional storage space for those pesky smaller items that often get lost – we'll leave the organising up to you.





Local Knowledge & Assistance

We know half the fun of building your dream 4x4 is getting your hands dirty. But we also know that sometimes, things don't go to plan. If in the pursuit to build the ultimate setup you find yourself off-track, we're here to help you get unstuck.

For further information call 07 3180 1470 or email info@kaon.com.au

Disclaimer: The products sold by KAON should not be modified, and are for use only on the vehicles specifically stated. KAON will not be liable for any damages arising out of the use or misuse of it's products. It is the customers responsibility to ensure the products are safely and properly used and installed. KAON consistently seeks to improve it's products and reserves the right to make changes to any product.